





| Bestell-Nr.:                              | Visuell   | Beschreibung  | Bezeichnung  |
|---|---|---|--|
| 60308<br>60309                            | Fallrohr-Fertigkonsole fvz<br>         | = F SP 30-30-2 250 mm lang<br>= F SP 50-40-3 250 mm lang  | F FRK 0<br>F FRK 1   |
| 60310<br>60311<br>60312<br>60313<br>60314 | Fallrohr-Fertigkonsole 250 mm lang<br> | = F SP 30-30-2 z bei Rohr DN 50<br>= F SP 30-30-2 z bei Rohr DN 70/80<br>= F SP 30-30-2 z bei Rohr DN 100<br>= F SP 30-30-2 z bei Rohr DN 125<br>= F SP 30-30-2 z bei Rohr DN 150 | F FRK 50 z<br>F FRK 70/80 z<br>F FRK 100 z<br>F FRK 125 z<br>F FRK 150 z |
| 60315                                     | Unterstützungshalter fvz<br>           | = F SP 50 60-40-4 LL 14x26mm  | F UH 50-1  |
| 60316                                     | Unterstützungshalter fvz<br>          | = F SP 50 -40-3 LL 14x26mm  | F UH 50-2  |
| 60317                                     | Unterstützungshalter fvz<br>         | = F SP 60 -40-4 LL 14x26mm  | F UH 50-3  |
| 60318                                     | Unterstützungplatte fvz<br>          | = F K 50-40-350; F K 50-40-550  | F USP 1  |
| 60319<br>60320<br>60321                   | Unterstützungslasche fvz<br>         | = F SP 50 60-40-35-4 Loch 9 mm<br>= F SP 50 60-40-35-4 Loch 14 mm<br>= F SP 50 60-40-35-4 Loch 17 mm  | F UL 50-08<br>F UL 50-12<br>F UL 50-16                                   |
| 60322                                     | Verbindungsplatte fvz 190 mm<br>     | = SP 50 60-40-4 Loch 14 mm  | F VL 50  |
| 60323                                     | Lochplatte fvz<br>                   | 120-75-5 Loch 13 mm   | F LP 1   |
| 60324                                     | Bodenthaler fvz<br>                  | = F SP 50-50 LL 14x26 mm<br>160-70-10mm   | F BH 50-50   |
| 60325                                     | Bodenthaler, 90 Grad, fvz<br>        | = F SP 50-50 LL 14x26 mm<br>160-70-10mm   | F BH 50-50 v   |



| <b>EDELSTAHL</b>             |  |                   |         |                             |                   |
|------------------------------|--|-------------------|---------|-----------------------------|-------------------|
| <b>Befestigungsteile V4A</b> |  |                   |         |                             |                   |
| 70624                        | <b>Ve-lasche V4A<br/>190mm</b>   | = SP 50           | 60-40-4 | Loch 14 mm                  | F VL 50 V4A       |
| 70625                        | <b>Lochplatte V4A</b>  | 120-75-5          |         | Loch 13 mm                  | F LP 1 V4A        |
| 70626                        | <b>Bodenhalter<br/>V4A</b><br>                        | = F SP 50-50      |         | LL 14x26 mm<br>160-70-10mm  | F BH 50-50 V4A    |
| 70627                        | <b>Bodenhalter, 90<br/>Grad, V4A</b><br>              | = F SP 50-50      |         | LL 14x26 mm<br>160-70-10mm  | F BH 50-50 v V4A  |
| 70628                        | <b>Doppel -<br/>Bodenhalter<br/>V4A</b><br>         | = F SP 50-100-4 d |         | LL 14x26 mm<br>200-120-10mm | F BH 50-100 V4A   |
| 70629                        | <b>Doppel<br/>Bodenhalter, 90<br/>Grad, V4A</b><br> | = F SP 50-100-4 d |         | LL 14x26 mm<br>200-120-10mm | F BH 50-100 v V4A |
| 70630                        | <b>Konsolenhalter<br/>V4A</b><br>                   | = F SP 50-50      |         | 160-59-40-4mm               | F KOH 50-50 V4A   |
| 70631                        | <b>Konsolenhalter<br/>V4A</b><br>                   | = F SP 50-50 v    |         | 160-59-40-4mm               | F KOH 50-50 v V4A |